



***IWAKI AMERICA
MAGNETIC DRIVE PUMP
SMX SERIES
INSTRUCTION MANUAL***



Thank you for selecting an Iwaki America SMX Series magnetic drive pump. This instruction manual explains the correct handling, maintenance, inspection and troubleshooting procedures for your pump. Please read through it carefully to ensure the optimum performance, safety, and long service of your pump.


Table of Contents

1	Unpacking and Inspection	2
2	Model Identification Guide.....	2
3	Specifications.....	3
	Materials of Main Components.....	4
	Description on Main Unit Body and Labels.....	5
4	Handling Instructions.....	6
5	Installation, Piping, and Wiring	9
	Installation Position	9
	Foundation Preparation.....	9
	Lifting	9
	Piping.....	10
	Suction Piping.....	11
	Discharge Piping.....	12
	Wiring	12
6	Operation	13
	Notes on Operation.....	13
	Start-Up Preparation	13
	Starting Operation.....	14
	Stopping Operation	15
7	Maintenance and Inspection	15
	Daily Inspection.....	15
	Periodic Inspection.....	16
	Wear Limits of Spindle, Bearing, Mouth Ring & Impeller Thrust	17
8	Troubleshooting	19
9	Parts Description and Exploded View	20
10	Disassembly and Assembly	23
11	Spare Parts.....	27
12	Weights and Dimensions	28


1 Unpacking and Inspection

Open the package and check that the product conforms to your order. Also, check each of the following points. For any problem or inconsistency, contact your distributor at once.

1. Check that the model number and the HP indicated on the nameplate conform to the specifications of your order.
2. Check that all the accessories you ordered are included.
3. Check that the pump body and parts have not been accidentally damaged or that any bolts or nuts have not been loosened in transit.



2 Model Identification Guide



- | | | | | | | | | | | | | | | | |
|----------------------------|------------------------------------|---|----------------|----------------|-----------------------------|---------------------|-----------------------------|-----------------------------|----------------------------|-----------------------------|-----------------------------|------------------|-----|-----|--|
| 1. | SMX
SMX-F | Polypropylene
ETFE | | | | | | | | | | | | | |
| 2. | Connections | 22: 1" x 1" Flanged
44: 1.5" x 1.5" Flanged
54: 2 x 1.5" Flanged | | | | | | | | | | | | | |
| 3. | Motor Rating | 0: 0.5 HP
1: 1.0 HP
2: 2.0 HP
3: 3.0 HP
5: 5.0 HP | | | | | | | | | | | | | |
| 4. | Bearing/Shaft/Outboard Thrust Ring | <table border="0"> <tr> <td style="text-align: center;">Bearing</td> <td style="text-align: center;">Spindle</td> <td style="text-align: center;">Outboard Thrust Ring</td> </tr> <tr> <td>CA/CF Carbon</td> <td>High Purity Alumina Ceramic</td> <td>High Purity Alumina Ceramic</td> </tr> <tr> <td>RA/RF PTFE (filled)</td> <td>High Purity Alumina Ceramic</td> <td>High Purity Alumina Ceramic</td> </tr> <tr> <td>KA/KK SiC</td> <td>SiC</td> <td>SiC</td> </tr> </table> | Bearing | Spindle | Outboard Thrust Ring | CA/CF Carbon | High Purity Alumina Ceramic | High Purity Alumina Ceramic | RA/RF PTFE (filled) | High Purity Alumina Ceramic | High Purity Alumina Ceramic | KA/KK SiC | SiC | SiC | |
| Bearing | Spindle | Outboard Thrust Ring | | | | | | | | | | | | | |
| CA/CF Carbon | High Purity Alumina Ceramic | High Purity Alumina Ceramic | | | | | | | | | | | | | |
| RA/RF PTFE (filled) | High Purity Alumina Ceramic | High Purity Alumina Ceramic | | | | | | | | | | | | | |
| KA/KK SiC | SiC | SiC | | | | | | | | | | | | | |
| 5. | Elastomer: | V: FKM | E:EPDM | | | | | | | | | | | | |
| 6. | Impeller: | X | Y | | | | | | | | | | | | |
| 7. | Motor Mounting: | U: NEMA C-Face | | | | | | | | | | | | | |

3 Specifications


Model	Connections	Impeller	Min Flow GPM	Standard Operating Point GPM - FT	Max Capacity GPM	Motor HP	Motor Frame	MAWP PSI	Weight w/motor lbs
SMX-(F)220	1" x 1"	Y	2.6	21 – 22	25	0.5	56C	41	48
SMX-(F)221		X		26 – 42	45	1.0			62
		Y		21 – 22	34	1.0			62
SMX-(F)222		X		26 – 42	45	2.0	145TC		72
SMX-(F)441	1.5" x 1.5"	Y	2.6	46 – 31	74	1.0	56C	48	64
SMX-(F)442		X		55 – 53	90	2.0	145TC		73
		Y*		40 – 38	77	1.5			73
SMX-(F)443		X		55 – 53	90	3.0			73
SMX-(F)543	2" x1.5"	Z	5.3	60 - 64	110	3.0	184TC	62	117
SMX-(F)545		Y		60 – 84	132	5.0			150
SMX-(F)545		X		60 - 95	132	5.0			150

Notes:

- Rated performance (head/capacity) represents the maximum discharge head/capacity measured with water at 68°F (20°C).
- Liquid temperature range: 32 - 176°F (0 - 80° C)
- Priming liquid volume:


SMX-(F)22	0.80 gal (3L)
SMX-(F)44	1.11 gal (4.2L)
SMX-(F)54	1.43 gal (5.4L)
- Self-priming performance of 13 ft in 90 seconds based on pumping clean water at ambient temperature of 68 °F (20 °C). Priming performance is reduced as liquid temperature increases.

■ **Materials of Main Components**



Component	Model	CA/CF	RA/RF	KA/KK
1. Front Case		GFRPP/CFRETFE		
2. Rear Case				
3. Rear Casing				
4. Volute Spacer				
5. Impeller				
6. Plate				
7. Magnet Capsule		PP/CFRETFE		
8. O-Ring		FKM/EPDM		
9. Gasket		FKM/EPDM		
10. Spindle		High purity alumina ceramic		SiC
11. Liner Ring		Alumina ceramic/SiC (KK)		
12. Rear Thrust		CFRPPS		
13. Rear Thrust Ring (RA/RF only)		-	Alumina ceramic	-
14. Bearing		Carbon	PTFE w/filler	SiC
15. Mouth Ring		PTFE w/ filler		

■ **Description on Main Unit Body and Labels**



CAUTION

When cleaning the pump, be careful not to wipe the nameplates, labels or pump body with solvent.

4 Handling Instructions

1. Dry Run Operation

Dry run operation of the pump may cause damage to the pump internally. The internal bushings used in the SMX series pump are lubricated and cooled by the fluid being pumped. If the pump is unavoidably or accidentally operated dry, with no obvious damage, allow the pump to cool down for a minimum of 20 minutes before attempting to restart. Do not allow fluid to enter the pump cavity until the pump has cooled down. Sudden or rapid introduction of a cold fluid may cause damage to the bearing system. A dry run protection device is recommended for the prevention of damage when dry pump operation is anticipated.

SMX models with the “CA” and "CF" bearing system are designed to tolerate brief or intermittent dry run operation. These models can tolerate dry run conditions for up to one hour. Longer dry run periods, or frequent dry running may result in premature wear of the bearing surfaces. This can rapidly affect the standard clearances of the rotating elements inside the pump. These pumps are designed to reduce the likelihood of cracking resulting from sudden cooling with liquid immediately after dry run operation. However, to ensure that this does not occur, Iwaki America recommends that the pump be allowed to cool for at least 20 minutes after dry running before introducing fluid again.

2. Priming water

The pump is a self-priming type. However, it is necessary for the operator to feed priming water into the pump before initiating operation. Make sure to feed the priming water (or operation liquid) up to the specified level before operation. Otherwise the pump may seize or get excessively worn.

Model	Amount of priming water
SMX-(F)22	0.8 Gal (3 Ltr)
SMX-(F)44	1.11 Gal (4.2 Ltr)
SMX-(F)54	1.43 Gal (5.4 Ltr)

3. Starting and stopping the pump

Pay close attention to the following points to avoid water hammer when starting and stopping pump operation. Extra attention is required if discharge-side piping is very long.

Starting and stopping the pump frequently will accelerate bearing wear. Starting/stopping in self-priming mode in particular should be limited to 1000 cycles.

- **Starting**

Prior to starting the pump, make sure that the power is turned OFF. Then carry out priming to fill the pump cavity with liquid (see Handling Instructions item #2). Close the cocks of any pressure or vacuum gauges to prevent damage from sudden pressure changes. Open only when taking measurements.

Next, open the valve on the discharge side. Now you can turn the power ON and start up the pump. Run the motor momentarily to check the direction of motor rotation. The motor should run in the direction indicated by the arrow sealed on the pump. If the direction is reversed, exchange two wires of the three-phase power wires.

- **Stopping**

When stopping the pump, first close the discharge valve gradually. When it is completely closed, turn off the power switch so that the pump stops. Never stop the pump suddenly by quickly closing a valve (i.e. solenoid or hydraulic valves).



Caution! Quick valve closure may cause water hammer which may result in severe damage to the pump.

4. Maximum system pressure rating

Be sure that the discharge pressure does not exceed the maximum pressure rating.

Model	Max. Temperature	Max Pressure Rating	
		PSI	MPa
SMX-(F)22	176°F (80°C)	40.60	0.28
SMX-(F)44	176°F (80°C)	47.85	0.33
SMX-(F)54	176°F (80°C)	62.37	0.43

5. Slurry liquids should not be handled.

6. Influence of specific gravity on pump performance

The performance of the SMX pumps does not change when pumping fluids of high specific gravity. However, the effect of specific gravity on shaft power and magnet coupling torque requirements must be considered in the selection of the appropriate model for your application. Maximum specific gravity than can be handled is 1.2.

7. Influence of liquid viscosity on pump performance

When pumping a high viscosity liquid, the discharge head and capacity of the pump may be higher than in the case of pure water. The required driving power may also vary and should be checked. Maximum allowable viscosity is 30 cP (contact factory for details).

8. Intermittent operation

Frequent start/stop switching shortens the service life of the pump. Limit the frequency of switching to six times or less per hour.

9. Effects of temperature

Temperature fluctuation may not change the performance of the pump itself. However, the liquid may change in terms of viscosity, pressure or corrosive properties. Pay special attention to changes in liquid characteristics as a result of temperature fluctuation.

Liquid temperature range, note self-priming performance is reduced as fluid temperature increases	32-176°F (pure water) (0-80°C)
Ambient temperature range (Freezing is not permissible.)	32-104°F (0-40°C)
Humidity range	35-85% RH

Refer to the corrosion resistance table for the temperature ranges recommended for various types of liquid. For inquiries or consultation, contact Iwaki America or your local distributor.

10. Separation of magnet coupling (decoupling)

If the magnet coupling should disconnect, stop the pump immediately. If operation is continued, the torque rating of the coupling will be permanently reduced.

5 Installation, Piping, and Wiring

■ *Installation Position*

1. Install the pump as close to the suction tank as possible. The installation position must be as low as possible, at a height within the self-priming limit that allows smooth pump performance.
If the surface level of the suction tank varies, measure the height from the lowest surface level as the maximum self-priming height to confirm that it will not exceed the self-priming limit. For details, consult Iwaki America or your distributor.
2. The pump can be installed indoors or outdoors. There should be sufficient space around the pump to enable efficient and easy maintenance. Safety measures should be taken not to expose the motor and power unit to flooding or other natural hazards.
3. Select an installation site that is flat and free of vibrations caused by nearby machines. There should be sufficient space for maintenance .

■ *Foundation preparation (before pump installation)*

1. The pump anchoring area must be greater than the area of the pump baseplate. If the anchoring area is not large enough, the baseplate may be damaged due to the concentration of loads placed on it.
2. Set the pump baseplate on a concrete foundation and fasten the anchor bolts tightly to prevent the pump from vibrating during operation. A sturdy metal (or reinforced) skid or platform is also an acceptable mounting surface.
3. In case of motor vibration during operation (e.g. sympathetic vibration with piping), an expansion joint should be provided between the pump and the piping before installation to prevent damage to pipes and gauges.

■ *Lifting*

When lifting the pump, please pay attention to the following points.

- Do not grab parts made of plastic (such as case, flange or base)
- The pump weighs between 48 and 150 lbs (with motor, depending on model).
It should be carried by two operators whenever possible.
- Always place the pump horizontally with its base down.


■ **Suction Piping**

1. The suction pipe can be used in either a suction lift or flooded suction condition. The shortest pipe possible, with the minimum number of bends, should be utilized. Arrange a proper support on the suction pipe so that the load and the thermal stress of the pipe itself are not applied to the pump.
2. Attach the coupling on the suction pipe carefully, so that no air enters the line. The presence of air in the suction pipe may prevent priming of the pump.
3. Avoid installations with poor suction conditions (e.g. vacuum in suction tank, large suction head or long suction piping). NPSHa should always be at least 2 feet greater than NPSHr. For NPSHr values, refer to the standard performance curve for your pump model or contact Iwaki America or your distributor.
4. When using a bend on the suction side, install a straight pipe which is more than 20 inches long or 10 times as long as the suction port diameter before the suction port of the pump. Use the largest possible radius of curvature for the bend.
5. Do not allow any projection where air may be trapped along the suction pipe. The suction pipe should have an ascending gradient toward the pump.
6. If the diameters of the pump suction port and the suction pipe are different, use an eccentric reducer pipe. Connect the eccentric reducer pipe such that the upper part of it is level. **Never use a suction pipe with a diameter smaller than that of the suction port.**
7. When using the flooded suction method, the suction pipe should be given a slight ascending gradient toward the pump so that no air pocket is created on the suction side.
8. The end of the suction pipe should be located 18 inches or more below the surface of the liquid.
9. A screen should be provided at the inlet of the suction tank to prevent the entrance of foreign matter into the suction pipe. Foreign matter may cause malfunctioning of the pump. The end of the suction pipe should be at least 1- 1.5D from the bottom of the suction tank. (D=Diameter of suction pipe).
10. When employing the suction lift method, install a foot valve on the suction pipe.
11. When using the flooded suction method, it is recommended that a gate valve be installed on the suction pipe for easier overhaul inspection of the pump. Since this valve is used only in the overhaul inspection of the pump, keep it fully opened during normal pump operation.
12. Pay close attention to the lowest level of the liquid in the suction tank so that air entrapment to the suction piping will not occur.
The inflow pipe into the suction tank should be distanced from the suction pipe and positioned below the liquid surface as a means of preventing air entrapment to the suction pipe. If air bubbles are generated in the suction tank, install a baffle.


13. It is recommended that a vacuum/pressure gauge be installed on the suction piping approximately 6 pipe diameters from the pump suction port.

■ **Discharge Piping**

1. Use proper pipe supports so that the weight of the piping does not load the pump nozzle.
2. If a method other than flooded suction is used, install a special pipe for priming.
3. If the piping is very long, its diameter should be determined by calculating the piping resistance. Otherwise, the specified performance may not be obtained due to increased piping resistance.
4. A check valve should be installed if any of the following conditions exists in the piping:
 - The discharge piping is very long.
 - The discharge head is 50 feet or more.
 - The end of the discharge pipe is located 30 feet higher than the surface of the suction tank.
 - Several pumps are connected in parallel with the same piping.
5. The installation of a gate valve on the discharge pipe is recommended for the adjustment of discharge quantity and for the prevention of motor overload. When installing both a check valve and a gate valve, the check valve should be positioned between the pump and the gate valve.
6. A pressure gauge must be installed on the discharge piping.
7. An air bleeding valve should be installed if the discharge pipe is very long in the horizontal direction.
8. A drain valve should be installed for the drainage of liquid if there is a chance that the liquid in the discharge pipe will freeze.



■ Wiring



M MOTOR
 MC MOTOR CONTACTOR
 ON — PUSH BUTTON
 OFF
 CLR OVERLOAD RELAY

Use appropriate wiring materials, follow the instruction manual for the motor and abide by the local and national electrical codes. In addition, follow the instructions given below:

1. Use a motor contactor that conforms to the specifications (voltage, current, etc.) of the pump motor.
2. If the pump is installed outdoors, use waterproof wiring to protect the switches from rainwater and moisture.
3. The motor contactor and push button should be installed a reasonable distance from the pump.
4. Refer to the wiring example shown on the left. (This example does not include the installation of a dry-operation prevention device. Follow the instruction manual of the dry-operation prevention device when installing it.)

6 Operation

■ *Notes on Operation*

1. Never operate the pump with the suction-side valve (gate valve) closed. Otherwise, the internal bushings of the pump will be damaged.
2. In the event of cavitation, stop the pump immediately.
3. If the magnet coupling disconnects, stop the pump immediately. The torque rating of the magnet coupling will be reduced if operation is continued with the coupling disconnected.
4. Liquid temperature fluctuation should not exceed 176° F when starting, stopping, and operating the pump.
5. Be sure to close the discharge valve completely before starting operation in order to prevent water hammer upon start-up.
6. The pump should never be operated for a lengthy period with the discharge valve closed. The resulting rise in temperature of liquid in the pump may cause damage to the pump.
7. In the event of a service power failure, turn off the power switch immediately and close the discharge valve.

■ *Start-Up Preparation*

When operating the pump for the first time after installation, and when restarting operation after a long interval, prepare for operation as described below.

1. Thoroughly clean the inside of the piping and pump.
2. Tighten the union fittings or flange connecting bolts and baseplate installation bolts. Check that bolts which couple the front casing and the bracket together are securely fastened.
3. Open the priming inlet cap on the top section of the pump and put liquid into the pump. After the pump is filled, fasten the priming inlet cap tightly to prevent air leaks. Some types of liquid used as priming may corrode the metal parts of the pump. Be careful not to spill water over the inlet. If liquid is spilled, clean pump thoroughly.
4. In the flooded suction method, measure the pressure in the suction pipe to confirm that the pump is filled with liquid.

5. Run the motor momentarily to check the direction of motor rotation. The motor should run in the direction indicated by the arrow on the nameplate of the pump. If the direction is reversed, exchange any two wires of the three-phase power wires.

Note: All Iwaki America SMX series pumps spin counter-clockwise when looking at the suction port of the pump. Naturally, from the motor fan side, this would be viewed as clockwise.

■ **Starting Operation**

Pump operation is detailed below.

Step	Check operation	Remarks
1	Verify valve position.	Suction valve fully open. Discharge valve fully closed.
2	Check that the pump is filled with liquid.	If pump is not filled with liquid, fill it in accordance with steps 3-4 of 'Start-up Preparation'.
3	Turn ON motor switch momentarily and check for correct direction of pump operation.	See the arrow on the casing to confirm the direction of rotation (clockwise when viewed from the motor fan side).
4	<p>Turn on power and start pump. Then adjust the discharge pressure and discharge volume.</p> <p>For suction lift method: Open the discharge valve fully. Start the pump and make sure the air is discharged. With the pump in a normal operating condition, close the discharge valve gradually to obtain the specified discharge pressure level. It takes approx. 3 minutes with pure water at room temp. to discharge the air out of the pump and the suction pipe completely.</p> <p>For flooded suction method: If the pump operates normally & the pressure gauge on the discharge side indicates the pressure at the maximum level, open the discharge valve gradually to obtain the specified discharge pressure level.</p> <ul style="list-style-type: none"> ▪ Open/close the discharge valve gradually within one minute and adjust the discharge pressure while checking the pressure gauge on the discharge side. (Or adjust the flow rate on the discharge side while checking the flow meter.) 	
5	Points to be observed during operation. If pump enters continuous operation condition, check flow meter and confirm that pump operation meets specifications.	If flow meter is unavailable, check values of discharge pressure, suction pressure and current in relation to piping resistance.

■ **Stopping Operation**

Step	Check operation	Remarks
1	Close discharge valve gradually.	 Caution! Do not cause sudden closure by using solenoid valve, etc. Otherwise, pump may be damaged by water hammer.
2	Stop motor.	Observe that the motor stops rotating slowly and smoothly. If not, check inside of pump.
3	Points to be observed when stopping pump. If pump operation is stopped in cold weather, liquid inside the pump cavity may freeze and damage the pump. Be sure to drain liquid completely. In case of short-term shut down, which does not allow removal of liquid, use band heater, etc., to prevent liquid from freezing. In case of service power failure turn OFF power switch and close discharge valve.	

7 Maintenance and Inspection

■ **Daily Inspection**

1. Check that the pump operates smoothly, without generating abnormal sounds or vibration.
2. Check the level of the liquid in the suction tank, and the suction pressure.
3. Compare the discharge pressure and current measured during operation with the specifications indicated on the motor and pump nameplates to verify normal pump load.

* Note that the indicated value of the pressure gauge varies in proportion to the specific gravity of the liquid.



Caution! The valve of the pressure gauge or vacuum gauge should be opened only when measurements are recorded. It must be closed after completion of each measurement. If the valve remains open during operation, the gauge mechanism may be affected by abnormal pressure caused by water hammer.

4. If a spare pump is included in the installation, keep it ready for use by operating it from time to time.

■ **Periodic Inspection**

To ensure efficient, smooth operation of the pump, carry out periodic inspection by following the procedure described below. When carrying out an overhaul inspection, handle the internal bushings and plastic components most carefully. Since the outer drive magnet and inner magnet capsule are very powerful, handle these components with caution. Take care not to trap hands and fingers between the magnets and metal objects. Also avoid positioning the magnets near any electronic device (or ATM cards with magnetic strips) that could be affected by a strong magnetic field.

1. After thorough decontamination of the pump, remove liquid end assembly from motor bracket.
2. Remove front casing from the liquid end.
3. Insert magnet capsule with impeller into rear casing.
4. Measure clearance between backside of impeller shroud and face of rear casing, dimension "A" shown on pages 17 and 18.

Inspection Interval	Part	Inspection Points	Operator Action
Every 6 months *Inspection record should be maintained.	Drive magnet assembly	<ul style="list-style-type: none"> ▪ Is there scoring? ▪ Is magnet mounted normally? Are hexagonal socket set screws loose? ▪ Are inner perimeter of magnet & motor shaft concentric? 	<ul style="list-style-type: none"> ▪ Contact your distributor if any abnormality is observed. ▪ Re-install magnet on motor shaft and fasten hexagonal socket set screws. ▪ Re-tighten or replace hexagonal socket set screws.
Every 3 months *Inspection record should be maintained.	Rear casing	<ul style="list-style-type: none"> Is there scoring on the inner diameter? Are there any cracks in liquid-containing section? Stain in rear casing? 	<ul style="list-style-type: none"> ▪ Contact your distributor if any abnormality is observed. ▪ Replace if abnormality is observed. ▪ Clean.
	Magnet capsule	<ul style="list-style-type: none"> ▪ Is there scoring in rear face or cylindrical body? ▪ Are there any cracks in the plastic of the rear section or cylindrical body? ▪ Bearing wear. 	<ul style="list-style-type: none"> ▪ Contact your distributor if any abnormality is observed. ▪ Contact your distributor if any abnormality is observed. ▪ Replace if any abnormality is observed. See tolerance chart.


Every 3 months *Inspection record should be maintained	Impeller	<ul style="list-style-type: none"> ▪ Are there any cracks? ▪ ▪ Are there any cavitation marks? ▪ Stain or clogging inside impeller ▪ Dimensional change of impeller ▪ Measure Mouth Ring thickness ▪ 	<ul style="list-style-type: none"> ▪ Replace if any abnormality is observed. ▪ Eliminate cause. <p>Clean</p> <p>Replace if any abnormality is observed.</p> <p>Replace if any abnormality is observed. See tolerance chart</p>
	Front casing	<p>Stain in liquid-containing section</p> <p>Are there any cracks?</p> <p>Wear or crack of front thrust ring</p> <p>Expansion or wear of o-ring</p> <p>Scoring on inner surface</p>	<p>Clean</p> <p>Replace if any abnormality is observed.</p> <p>Contact your distributor if any abnormality is observed.</p> <p>Replace if part is damaged</p> <p>Contact your distributor if any abnormality is observed.</p>
	Spindle	<p>Are there any cracks?</p> <p>Wear on surface</p>	<p>Replace if any abnormality is observed.</p> <p>Replace if wear limit is exceeded.</p>

■ **Wear Limits of Spindle, Bearing, Mouth Ring & Impeller Thrust**

SMX-(F)22/SMX-(F)44	New Inches (mm)	Replace Inches (mm)
Bearing I.D.	0.709 (18.0)	0.748 (19.0)
Spindle O.D.	0.709 (18.0)	0.693 (17.0)
Thickness of mouth ring	0.295 (7.5)	0.217 (5.5)
SMX-(F)54	New Inches (mm)	Replace Inches (mm)
Bearing I.D.	0.945 (24)	0.984 (25)
Spindle O.D.	0.945 (24)	0.906 (23)
Thickness of mouth ring	0.295 (7.5)	0.217 (5.5)

1. If the difference between Bearing I.D. and Spindle O.D. exceeds 0.039 in (1mm), either the bearing or the spindle, whichever has the greater wear, should be replaced regardless of the values in the above table. In case of a ceramic bearing type pump, the spindle and the bearing should be replaced simultaneously.

2. Initial wear may appear on the sliding parts during the first stages of operation. This should not be mistaken for an abnormal condition.
3. The step between the surfaces of the mouth ring and the impeller upon shipment is 0.079 in (2mm). Replace the mouth ring when this step is reduced to 0 in.




8 Troubleshooting

Trouble	Causes	Troubleshooting
Self-priming is impossible or slow. The pump does not self-prime repeatedly.	The amount of priming liquid is insufficient. The pump is operated dry.	Stop the pump and feed a sufficient amount of priming liquid. Then restart the pump.
	The discharge valve is closed. The air bleeding pipe is closed.	<input type="checkbox"/> Open the valve fully and restart the pump.
	Air enters inside the pump from the suction pipe of the gasket.	<input type="checkbox"/> Re-check the sealing condition of the coupling flange surfaces on the suction pipe. <input type="checkbox"/> Check to ensure that the water suction level is not too low.
	The magnet coupling has disconnected.	<input type="checkbox"/> Measure the current to make sure that the pump is not overloaded. <input type="checkbox"/> Check the impeller and the magnet capsule for any foreign matter between these parts. <input type="checkbox"/> Check that the voltage level is at a normal level.
	The RPM of the pump is insufficient. The pump rotates in the wrong direction.	<input type="checkbox"/> Check the wiring and the motor and take necessary measures. <input type="checkbox"/> Exchange the connected wires.
	The pump is positioned too high.	<input type="checkbox"/> Install the pump to a height within the self-priming limit. <input type="checkbox"/> Check to ensure that the water suction level is not too low.
	The specific gravity or viscosity of the liquid is not suitable. The temperature of the liquid is too high.	<input type="checkbox"/> Check the temperature, specific gravity and viscosity of the liquid and take necessary measures.
	The suction pipe is too long.	<input type="checkbox"/> Shorten the suction pipe.
	The frequency is not suitable for the pump.	<input type="checkbox"/> Adjust the frequency to the pump.
	The suction pipe is blocked with foreign matter. The discharge pipe is blocked with foreign matter.	<input type="checkbox"/> Remove the foreign matter. <input type="checkbox"/> Take measures not to allow the entry of foreign matter.
	The suction hose is deformed.	<input type="checkbox"/> Change the hose to a new one having a higher rigidity.
	The ends of the discharge pipe and the air bleeding pipe are positioned below the water surface.	<input type="checkbox"/> Raise the ends of the pipes above the water surface.
The suction flange or the cap is loosened.	<input type="checkbox"/> Check the o-ring and tighten if necessary.	

Trouble	Causes	Troubleshooting
Discharge rate is too low.	The suction port is blocked with foreign matter and smooth discharge of liquid is not possible.	<input type="checkbox"/> Remove the foreign matter from the suction port.
	An air pocket has been created inside the suction pipe.	<input type="checkbox"/> Check the piping conditions and adjust the pipe as necessary.
	The inlet of the impeller is blocked with foreign matter.	<input type="checkbox"/> Disassemble the impeller section partially and remove the foreign matter. <input type="checkbox"/>
	Air enters inside the pump from the suction pipe or the gasket.	<input type="checkbox"/> Check the suction pipe joint and retighten it as necessary.
	The pump discharge side is blocked with foreign matter.	<input type="checkbox"/> Remove the foreign matter from the pump. <input type="checkbox"/> Remove the foreign matter and/or scales from the pipe.
	The suction pipe has an air pocket or other type of piping resistance.	<input type="checkbox"/> Check the suction pipe for any projection and take necessary measures.
	The discharge pipe has a resistant section or the actual pump head and loss of head are too high.	<input type="checkbox"/> Measure the actual pump head and the loss of head of the discharge pipe and take necessary measures.
The motor is overheated.	The voltage has dropped greatly. The motor is overheated.	<input type="checkbox"/> Exchange the connected wires. <input type="checkbox"/> Check the voltage and the frequency. <input type="checkbox"/> Check to ensure that the specific gravity and viscosity of the liquid are suitable.
	The ambient temperature is too high.	<input type="checkbox"/> Ventilate the motor well.
The discharge rate has dropped suddenly.	The suction port is blocked with foreign matter.	<input type="checkbox"/> Remove the foreign matter.
Pump vibrates excessively.	The base is not anchored firmly. The installation bolts are loosened. The suction pipe is blocked or closed, resulting in cavitation. The pump bearing is worn or melted. The magnet capsule or the spindle is damaged. The dynamic balance of the driving magnet has changed. The impeller is in contact with the magnet capsule anchoring part. The motor bearing is worn.	<input type="checkbox"/> Reinstall the base. <input type="checkbox"/> Retighten the bolts. <input type="checkbox"/> Clean the pump and get rid of the cause of the cavitation. <input type="checkbox"/> Replacement. <input type="checkbox"/> Replacement. <input type="checkbox"/> Remove the cause or replace the part. <input type="checkbox"/> Replacement. <input type="checkbox"/> Replace the bearing or the motor.

9 Parts Description and Exploded View



Parts Description SMX-22/44 Polypropylene

No.	Description	Material	Qty	Remarks	No.	Description	Material	Qty	Remarks
1	Front Case	GFRPP	1		18.4	Spring Washer	SS	3	M8
2	Rear Casing	GFRPP	1		19	Flange	GFRPP	2	
3	Rear Case	GFRPP	1		20.1	Rear Casing Support	Ductile Iron	1	
4	Volute Spacer	GFRPP	1		20.2	Motor Bracket	Ductile Iron	1	
6	Plate	GFRPP	1		23	Base	GFRPP	1	
7	Fill Cap		1		26.1	Rear Thrust Ring	Alumina Ceramic	1	
8	Drain Cap		1		26.2	Rear Thrust Collar	CFRPPS	1	RA type only
13.1	Hex Socket Cap Bolt	SS	6 or 8	M8X40	27	Spindle	Alumina Ceramic/Sic	1	
13.2	Hex Socket Cap Bolt	SS	3	M8X15	30	Gasket	FKM/EPDM	1	
13.3	Hex Socket Cap Bolt	STL	4	M8X20 PW/SW	31.1	O-ring (casing)	FKM/EPDM	1	G-160
13.4	Hex Socket Cap Bolt	SS	2	M8X85*	31.2	O-ring (drain)	FKM/EPDM	1	G-25
14.2	Hex Head Bolt	SS	4	M10X25	31.3	O-ring (inner case)	FKM/EPDM	1	G-40/50
15	Stud Bolt	SS	5		31.4	O-ring (cap)	FKM/EPDM	1	G-30/40
16.1	Nut	SS	13	M8	31.5	O-ring (flange)	FKM/EPDM	2	
16.2	Cap Cover	PE	13		10	Drive Magnet Assm		1	
17	Pan Washer	SS	21	M8	11	Magnet Cap Assm		1	
18.1	Spring Washer	SS	13	M8	9	Impeller Assm	GFRPP/PTFE	1	Includes mouth ring
18.3	Spring Washer	SS	4	M10					

* SMX-44 only

Parts Description SMX-F22/44 CFRETFE

No.	Description	Material	Qty	Remarks	No.	Description	Material	Qty	Remarks
1	Front Case	CFRETFE	1		18.4	Spring Washer	SS	3	M8
2	Rear Casing	CFRETFE	1		19	Flange	GFRPP	2	
3	Rear Case	CFRETFE	1		20.1	Rear Casing Support	Ductile Iron	1	
4	Volute Spacer	CFRETFE	1		20.2	Motor Bracket	Ductile Iron	1	
6	Plate	CFRETFE	1		21	Cap	PE	1	
7	Fill Cap	CFRETFE	1		23	Base	GFRPP	1	
8	Drain Cap	CFRETFE	1		26.1	Rear Thrust Ring	Alumina Ceramic	1	RF Type only
13.1	Hex Socket Cap Bolt	SS	8/6*	M8X40/45*	26.2	Rear Thrust Collar	CFRETFE	1	
13.2	Hex Socket Cap Bolt	SS	3	M8X15	27	Spindle	Alumina Ceramic/Sic	1	
13.3	Hex Socket Cap Bolt	STL	4	M8X20 PW/SW	30	Gasket	FKM/EPDM	1	
14.2	Hex Head Bolt	SS	4	M10X25	31.1	O-ring (casing)	FKM/EPDM	1	G-160
15	Stud Bolt	SS	5		31.2	O-ring (drain)	FKM/EPDM	3	G-25
16.1	Nut	SS	13	M8	31.3	O-ring (inner case)	FKM/EPDM	1	P-40/50
16.2	Cap Cover	PE	13		31.4	O-ring (cap)	FKM/EPDM	1	G-30/40
17	Pan Washer	SS	13/21*	M8	10	Drive Magnet Assm		1	
18.1	Spring Washer	SS	5/13*	M8	11	Magnet Cap Assm		1	
18.3	Spring Washer	SS	4	M10	9	Impeller Assm	CFRETFE /PTFE	1	Includes mouth ring

* SMX-(F)44 only

Parts Description SMX-54 Polypropylene

No.	Description	Material			Qty	Remarks
		CA	RA	KA		
1	Front Case	GFRPP			1	
2	Rear Casing	GFRPP			1	
3	Rear Case	GFRPP			1	
4	Volute Spacer	GFRPP			1	
6	Plate	GFRPP			1	
7	Fill Cap	GFRPP			1	
8	Drain Cap	GFRPP			1	
9	Impeller Unit	GFRPP			1	
10	Drive Magnet Unit	GFRPP			1	
11.1	Magnet capsule unit	Rare earth magnet + Ductile iron			1	
11.2	Lock pin	Rare earth magnet + PP			2	
12	Hex socket set screw	GFRPPS			2	M8 x 10
13.1	Hex socket head bolt	Steel			6	M10 x 50
13.2	Hex socket head bolt	Stainless Steel			3	M10 x 16
13.3	Hex socket head bolt	Stainless Steel			4	542, 543: M8 x 20 PW, SW 545: M10 x 16
13.4	Hex socket head bolt	Stainless Steel			2	M10 x 90
14.1	Hex head bolt	Stainless Steel			4	542, 543: M10 x 30 545: M12 x 40
14.2	Hex head bolt	Stainless Steel			4	542, 543: M10 x 25 545: M10 x 30
15	Stud bolt	Stainless Steel			5	
16.1	Nut	Stainless Steel			13	M10
16.2	Cover cap	PE			13	
17.1	Plain washer	Stainless Steel			21	M10
17.2	Plain washer	Stainless Steel			4	M10 only 545 type
18.1	Spring washer	Stainless Steel			13	M10
18.2	Spring washer	Stainless Steel			4	542, 543: M10 545: M12
18.3	Spring washer	Stainless Steel			4	M10
18.4	Spring washer	Stainless Steel			3	M10
18.5	Spring washer	Stainless Steel			4	M10 only 545 type
19.1	Flange 40A	GFRPP			1	40A
19.2	Flange 50A	GFRPP			1	50A
20.1	Rear casing support	Ductile iron			1	
20.2	Bracket	Ductile iron			1	
22	Motor	-----			1	
23	Base	542, 543 GFRPP			1	
24	Liner ring	545 SPCC			2	
26	Rear thrust	Alumina ceramic 99.5%			1	
27	Spindle	Alumina ceramic 99.5%	SiC		1	
28	Bearing	Alumina ceramic 99.5%	SiC		1	
29	Mouth ring	Carbon	Filled PTFE	SiC	1	
30	Gasket	Filled PTFE			1	
31.1	O-ring for rear casing	V: FKM E: EPDM			1	G-180
31.2	O-ring for drain cap				1	G-25
31.3	O-ring for rear case				1	G-55
31.4	O-ring for Cap				1	G-30
31.5	O-ring for flange 40A				1	AS568-120
31.6	O-ring for flange 50A				1	AS568-136

10 Disassembly and Assembly



Caution!

Since the magnets used in the pump are very powerful, be careful not to get your fingers caught between the elements during disassembly or assembly. Also, keep the magnet away from any electronic device (or ATM card with a magnetic strip) that could be affected by a strong magnetic field.

Prior to servicing, the suction and discharge valves must be closed. The piping and the pump often retain some liquid. It is recommended that the piping and pump cavity be drained prior to servicing.


If dangerous liquid is handled, wear protection and flush pump with clean water or decontaminant prior to service.




Make sure power to the motor is OFF.

■ **Disassembly**


1. Remove the pump drain to discharge the liquid out of the pump (note not all liquid will be removed).




2. Next, loosen the four hex head bolts on the motor bracket to remove the pump head from the motor.




3. Remove the three hex socket cap head bolts that secure the rear casing support to the rear casing.



4. Remove all cover caps and the five nuts securing the front casing. At this point any remaining liquid can be drained from the pump.



5. Separate the rear casing support, rear casing and impeller + magnet capsule unit at one time from the rear case. Note, magnet capsule should be kept free of all metal chips. Store in a clean area.




6. Remove the remaining nuts securing the front and rear cases and separate.

7. Remove the gasket and the plate. Take care not to damage the seal faces or the gasket.
8. The impeller and magnet capsule assembly can no be removed and inspected. To remove the impeller, tap the back side of the impeller with a plastic hammer while securely holding the magnet capsule. If the impeller cannot be removed in this manner, place the impeller and magnet capsule in hot water (approx. 194°F, 90°C) for five minutes, then repeat above step.
9. To remove drive magnet assembly, stand motor with motor bracket on end (vertically). Loosen 2 set screws with a socket screw key, accessible thru the hole located at the bottom of the motor bracket.
10. Extract drive magnet assembly from motor shaft using a puller or a screwdriver as a handspike. Keep it free of all metal chips and particulate.

■ **Assembly**


Reassemble the pump by reversing the order of disassembly. Take care not to contaminate or damage the seal faces for o-rings and case gasket. Tighten bolts uniformly to prevent uneven -oring and gasket compression.

1. Place the drive magnet assembly onto the motor shaft. Ensure that the end of the motor shaft is flush with that of the drive magnet boss. Tighten it with two setscrews. Apply Loctite 242 (or equal) as necessary. Check that there is no foreign matter adhering to magnets.
2. Secure drain cap with o-ring to front case drain.
3. Fit the gasket to the groove in the plate. Check to make sure there is no damage to gasket or seal faces.
4. Mount the inner case o-ring and plate to front case. Insert volute spacer into rear case (if needed – note mounting direction).



5. Lay the rear case on flat surface, impeller side down. Place front case and plate assembly on rear case. Temporarily tighten the hex socket head bolts to secure the assembly and prevent the o-ring and gasket from moving.


6. Insert the spindle into the rear casing after positioning the rear thrust collar (and rear thrust ring for RA types).
7. Install impeller to magnet capsule assembly.
Align the impeller and magnet capsule, and with an arbor press, press the impeller into the magnet capsule assembly. Make sure the through hole on the magnet capsule is aligned with the u-shaped hole in the impeller and there is no gap between the edge of impeller spline and the bearing. Note: Use a flat surface material greater than the mouth ring for proper alignment. Should the impeller be hard to insert, place magnet capsule in hot water (approx. 194°F, 90°C) for five minutes, then assemble impeller to magnet capsule assembly.



8. Place O-ring into front casing then slide the impeller magnet assembly onto the spindle. Take care not to chip bearing or spindle edges when re-assembling.
9. Mount front casing with O-ring onto rear casing.
10. Place the rear casing support onto assembly and temporarily tighten the three socket head cap bolts. Use torque wrench in cross pattern to complete tightening of all bolts per table below.

Bolt Size	Fastening Torque	
	LBF.IN	N-m
M8	104.4	11.8
M10	130.1	14.7

11. Carefully place the pump head assembly back into the motor bracket. If the motor and drive magnet are mounted to bracket, spacers can be used to prevent injury from attraction between magnets.



12. Check with a screwdriver that motor-fan rotates smoothly/freely.

11 Spare Parts


Appropriate spare parts are necessary to ensure continuous pump operation. Expendable parts, such as bearings, spindles and mouth (thrust) ring should always be kept on hand. Consult your distributor or Iwaki America for the correct part number and pricing. When placing orders, supply the following information.

1. Description and item number (according to this instruction manual).
2. Pump model number and serial number (as shown on the nameplate of the pump).
3. Drawing number if you have received a certified drawing.

12 Weights and Dimensions

Pump Weight without motor:

SMX-(F)220	28.7 lbs (13 kg)
SMX-(F)221	34.2 lbs (15.5 kg)
SMX-(F)222/441	35.3 lbs (16 kg)
SMX-(F)442/443	36.4 lbs (16.5 kg)
SMX-(F)543	61.8 lbs (28 kg)
SMX(F)545	79.4 lbs (36 kg)




inches (mm)


Model	a	b	c	d	e	f	g	j	k	m	n	p	r	s	H	L*	HP/Frame
SMX-(F)220							12.13 (308)									21.22 (539)	0.5/56C
SMX-(F)221	4.92 (125)	0.98 (25)	6.38 (162)	2.91 (74)	10.04 (255)	9.45 (240)	12.60 (320)								12.95 (329)	21.77 (533)	1.0/56C
SMX-(F)222							13.07 (332)	7.87 (200)	4.53 (115)	0.59 (15)	8.18 (208)	10.24 (260)	1.42 (36)	0.55 (14)		23.89 (697)	2.0/145TC
SMX-(F)441							14.41 (366)									23.58 (599)	1.0/56C
SMX-(F)442	5.51 (140)	1.57 (40)	7.40 (188)	3.66 (93)	10.67 (271)	11.22 (285)	14.88 (378)								14.33 (364)	25.69 (652)	2.0/145TC
SMX-(F)443							14.88 (378)									25.69 (652)	3.0/145TC
SMX-(F)543	6.10 (155)	1.89 (48)	8.02 (204)	3.93 (100)	11.36 (288)	12.18 (309)	15.52 (394)	7.86 (200)	5.12 (130)		8.17 (208)	10.22 (260)	0.55 (14)	1.41 (36)	15.29 (388)	26.71 (678)	3.0/145TC
SMX-(F)545			8.03 (204)	3.94 (100)	11.38 (289)	12.20 (310)	16.59 (421)	10.24 (260)		0.13 (3.3)	9.06 (230)	10.24 (260)	1.42 (36)	0.55 (14)	15.31 (389)	30.28 (769)	5.0/184TC

* Varies according to motor manufacturer.

SMX-(F)545 Dimensions



SMX-(F)54_ Dimensions



*Varies with motor manufacturer

