


EWN Exploded View Pump Components

W A L C H E M

IWAKI America Inc.



Type	Part No.	Description
Control Unit	EWNBR1	Control Unit, R-Type, EWN-B, 115V
	EWNBR2	Control Unit, R-Type, EWN-B, 230V
	EWNBY1	Control Unit, Y-Type, EWN-B, 115V
	EWNBY2	Control Unit, Y-Type, EWN-B,230V
	EWNCR1	Control Unit, R-Type, EWN-C, 115V
	EWNCR2	Control Unit, R-Type, EWN-C, 230V
	EWNCY1	Control Unit, Y-Type, EWN-C, 115V
	EWNCY2	Control Unit, Y-Type, EWN-C, 230V
Drive Unit Asm. *Includes bracket spacer & gasket	WNB11	Drive Assembly, EWN-B11, 115V/230V
	WNB16	Drive Assembly, EWN-B16, 115V/230V
	WNB21	Drive Assembly, EWN-B21, 115V/230V
	WNB31	Drive Assembly, EWN-B31, 115V/230V
	WNC16	Drive Assembly, EWN-C16, 115V/230V
	WNC21	Drive Assembly, EWN-C21, 115V/230V
	WNC31	Drive Assembly, EWN-C31, 115V/230V
Bracket Spacer	EH2378	Spacer, Bracket, EWN09
	EH1690	Spacer, Bracket, EWN11
	EH1431	Spacer, Bracket, EWN16
	EH1700	Spacer, Bracket, EWN21
Gasket	EH1573	Gasket, Pump Head, EWN09-21
	EH1574	Gasket, Pump Head, EWN31
	EH1575	Gasket, Pump Head, EWN36